



...more than 120.000 FLEXTUBs supporting the airport industry worldwide!



CRS FLEXTUB - Maintenance

Special precautions for storage

After unpacking new FLEXTUB from the supplier - do not stack more than 20 pieces per stack. FLEXTUB should be stored under normal storage temperature out of direct sunlight and on a flat surface.

Special precautions for use

High temperature exposure can cause severe damage and skewness to the FLEXTUB, if not stored as described. Risk of deformation if FLEXTUB is wedged in- or -outside the transportation facility.

Miscellaneous

The FLEXTUB products generally has excellent resistance to water, moisture and chemicals. Cleaning FLEXTUB - use normal household cleaners.

